

## Marelli SRA-TN communication protocol

Channels received by AIM loggers connected to Marelli SRA-TN ECU are:

<b>ID</b>	<b>CHANNEL NAME</b>	<b>FUNCTION</b>
ECU_1	SRA_RPM	ROM
ECU_2	SRA_TPS	Throttle position sensor
ECU_3	SRA_ECT	Engine cooling temperature
ECU_4	SRA_OILT	Oil temperature
ECU_5	SRA_AIRT	Intake air temperature
ECU_6	SRA_BAP	Barometric air pressure
ECU_7	SRA_OILP	Oil pressure
ECU_8	SRA_FUELP	Fuel pressure
ECU_9	SRA_BATTV	Battery supply
ECU_10	SRA_LAMBDA	Lambda value