

Racetech EM35/EM36/EM38 communication protocol

Channels received by AIM loggers connected to Racetech EM35/EM36/EM38 ECU are:

| ID | CHANNEL NAME | FUNCTION |
|-----------|---------------------|----------------------------|
| ECU_1 | RTD_RPM | RPM |
| ECU_2 | RTD_TPS | Throttle position sensor |
| ECU_3 | RTD_BARO | Barometric sensor |
| ECU_4 | RTD_IAT | Intake air temperature |
| ECU_5 | RTD_ECT | Engine cooling temperature |
| ECU_6 | RTD_IGN_ADV | Ignition advance |
| ECU_7 | RTD_INJ_TIME | Injection time |
| ECU_8 | RTD_BATTERY | Battery supply |
| ECU_9 | RTD_LAMBDA | Lambda value |