#### AiM InfoTech

# DUQUEINE – D09\_V35A\_V51

#### Release 1.00







1

### Supported models and years

This user guide explains how to connect Duqueine's ECU to AiM devices. Supported models are:

Duqueine D09 LMP3 (V35A engined – V51)

from 2025 onwards

2

### Wiring connection

These models are equipped with a specific manufacturer protocol based on CAN, accessible through the CAN Data Camera connector located on the left of the driver's headrest. The connector to use is a DTM04 4 pins shown here below with its connection table.



DTM 04-4P pin nr	Function	AiM cable	AiM colour cable
2	CAN High	CAN +	White
3	CAN Low	CAN -	Blue



3

## Race Studio configuration

Before connecting the AiM device to the ECU, set all functions up using AiM **RaceStudio 3 software only**. The parameters to set in the device configuration are:

• ECU manufacturer: **DUQUEINE** 

ECU Model: D09\_V35A\_V51 (RaceStudio 3 Only)

4

## "DUQUEINE - D09\_V35A\_V51" protocol

Channels received by AiM devices configured with "DUQUEINE - D09\_V35A\_V51" protocol are:

CHANNEL NAME	FUNCTION
RPM	Engine RPM
rPedal	Pedal position sensor
Gear	Engaged gear
aSteering	Steering position angle
pBrakeF	Brake pressure front
pBrakeR	Brake pressure rear
vBarrel	Barrel voltage
CarSpeed	Vehicle speed
WSpeed FL	Wheel speed front left
WSpeed FR	Wheel speed front right
WSpeed RL	Wheel speed rear left
WSpeed RR	Wheel speed rear right
VTankLevelEstd	Estimated fuel level volume
VFuelConsLap	Fuel consumption per lap volume
vFuelCons	Fuel consumption from fill up volume

#### InfoTech



BattVolt Battery voltage

tWater Water temperature

tAir Intake air temperature
tOil Engine oil temperature
tOilGbx Gearbox oil temperature

tExhaust Exhaust temperature bank 1 tExhaust2 Exhaust temperature bank 2

Lbd1OutRich Lambda bank 1
Lbd2OutRich Lambda bank 2

BrakeTempFL

Brake temperature front left

BrakeTempFR

Brake temperature front right

TPMSFLTemp

TPMS front left tire temperature

TPMSRRTemp

TPMS rear left tire temperature

TPMSRRTemp

TPMS rear right tire temperature

AirCompTemp Air compressor temperature
Tspare5 Spare temperature input 5
Tspare6 Spare temperature input 6

pWater Water pressure

pOil Oil pressure

pRail Fuel rail pressure

pFuel Fuel low pump pressure

pClutch Clutch pressure

pBaro Barometric pressure

TPMSFLPressure TPMS front left tire pressure
TPMSFRPressure TPMS front right tire pressure
TPMSRLPressure TPMS rear left tire pressure
TPMSRRPressure TPMS rear right tire pressure

AirCompPressur

xDamper FL

xDamper FR

Damper position front left

xDamper FR

Damper position front right

xDamper RL

Damper position rear left

#### InfoTech



xDamper RR Damper position rear right

SwFuelP2 State Fuel pump 2 switch state

SwResAlarmState Reset alarm switch state

AirCompState Air compressor state

DashAlarm Dash alarm

ELB EngineSN ELB engine serial number

eWG1lrn Report Electrical wastegate 1 learning report eWG2lrn Report Electrical wastegate 2 learning report

PedThrLearnState Throttle pedal learn state
PedThrLearnTime Throttle pedal learn timer
RotPedal Pos Pedal rules rotary position

RotTCPos Traction control rotary selector

SwForceFPState Force fuel pump switch state

Ignition Ignition power state
IgnLim Active Ignition active limiter

IgnLimAbs Ignition absolute engine limiter
SwFCYState Full course yellow switch state

FCYiSpeed Full course yellow limiter speed selection

PITTgtSpeed Pit limiter target speed

PITiSpeed Pit limiter speed selection

SwPitLimStatePit limiter switch stateSwHeadRestStateHeadrest switch stateSwRainLightStateRain light switch state

TCState Traction control enable

rdElementFront 3<sup>rd</sup> element front

SwFuelLowState Low fuel switch state

Dash LumLed Dashboard LEDs brightness
Dash LumDisp Dashboard display brightness

An9Corr Analog 9

ELB EngTime ELB engine time

ELB TotalKm ELB engine total mode kilometres

ELB EngKm ELB engine kilometers

#### InfoTech



PbuCh1Cur Powerbox channel 1 current
PbuCh2Cur Powerbox channel 2 current
PbuCh8Cur Powerbox channel 8 current
PbuCh9Cur Powerbox channel 9 current

SRG Beacon Lap beacon

LogCurrentLap Current lap number

LogLapTime Lap time

Act LapTime Actual lap time

BestLapTime Best lap time

ParDiffBestTime Partial difference from best time

AuxLapDiffBestTi Lap difference withAnalog 9 best time

**Please note**: not all data channels outlined in the ECU template are validated for each manufacturer's model or variant; some of the outlined channels are model and year specific, and therefore may not be applicable.